

Building manual v0.1

Frame Assembly 1

Materials:

- 32 x Nut 8 M8
- 32 x DIN 912 M8 20mm
- 12 x DIN 912 M8 16mm X
- 2 x Profile 4080 1440mm
- 1 x Profile 4080 1620
- 1 x Profile 4080 1700
- 4 x Brackets 80x80
- 4 x Top brackets

Notes:

- use a DIN 875 to make the corners square
- assembly on a flat surface

Frame Assembly 2

Materials:

- 32 x Nut 8 M8
- 32 x DIN 912 M8 20mm
- 12 x DIN 912 M8 16mm X
- 2 x Profile 4080 1440mm
- 1 x Profile 4080 1620
- 1 x Profile 4080 1700
- 4 x Brackets 80x80
- 4 x Top brackets

Notes:

• It is a copy of the frame assembly 1



- From the longest side, the distance between a pillar and the side is 385
- From the shortest side, the distance between a pillar and the side is 340

- Materials:
 - 128 x Nut 8 M8
 - 128 x DIN 912 M8 20mm
 - 8 x Profile 4080 700mm
 - 32 x Brackets 40x80

08.2018

Building manual v0.1

Z Axis Assembly

Materials:

- 8 x Z Holder POM
- 16 x 6301 Ball Bearings
- 4 x 20mm 4 Pitch Lead Screw 1000mm
- 1 x Closed Belt 6000mm
- 1 x Stepper Nema 24
- 1 x Nema 24 Z Holder POM
- 5 x Pulley T5 10mm 24
- 6 x DIN 912 M8 30mm
- 24 x DIN 912 M8 40mm
- 42 x Washers M8 30mm
- 12 x Washers M8
- 12 x 628 ball bearings
- 4 x DIN 984 M4
- 4 x DIN 912 M4 25mm
- 24 x Nut 8 M8
- 4 x Brackets 40x40
- 4 x Brackets 40x80
- 8 x DIN 912 M8 16mm
- 16 DIN 912 M8 20mm





Notes:

- Make sure the belt is tensioned to allow a fluid movement between all the axis
- Keep an equal distance between the POM holders

Daniele Ingrassia 08.2018

uilding manual v0.1



Materials:

- 2 x Profile 3060 1590mm, pre-drilled
- 2 x Profile 3030 X 2 1259mm, pre-drilled
- 16 x DIN 912 M6 20mm X 16
- 16 x Nut8 M6
- 4 x Bracket 30x60

- use a DIN 875 to make the corners square
- assembly on a flat surface Daniele Ingrassia 08.2018

Lower Bed Installation

Materials:

- 4 x POM Z Bed
- 32 x Nut 8 M5
- 32 x DIN 912 M5 20mm
- 4 x Brass Nut TR20 4mm Pitch
- 24 x DIN 912 M5 70mm
- 24 x DIN 985 M5
- 32 x Washers M5



Notes:

Lose the belt, make the lower bed flat by rotating the lead screws and then close the belt again

Building manual v0.1

Upper Bed Assembly

Building manual v0.1 Daniele Ingrassia 08.2018

Materials:

- 9x ISO 7380 M8 80mm
- 9 x Washer M8
- 9 x Nut 8 M8
- 2 x 70x30mm Rectangle profile 1530mm
- 2 x 70x30mm Rectangle profile 1379mm
- 2 x Profile 6030 1590mm
- 1 x Profile 3030 1590mm

Notes:

 The 7380 screws have to go through the 70x30 profiles



38 x Alu brackets 30x70x0.8mm 1500mm

parallel to the bed frame



- Washer M8 30mm X 4
- DIN 985 X 4

Manually drill the holes on the corners

Inner Enclosure



Materials:

- 4 x Alu Brackets 40x40x2mm
- 214 x Nut 8 M8
- 214 x ISO 7380 M8 12mm
- 40 x DIN 912 M8
- 40 x DIN 985 M8
- 12 x Side Alu Plates
- 2 x Bottom Alu Plates





- Slightly move the side and bottom 4080 profiles to fit the aluminium plates
- The plates with smaller holes are attached to the back
- Drill the 40x40 brackets by marking the hole positions from the side panels
- The bottom back plate has an hole for the motor



- 2 x Alu Profile 2020 1520mm
- 4 x Alu Profile 2020 229mm
- 8 x Alu Profile 2020 95mm
- 4 x Alu Profile 2020 220mm
- 4 x Alu Profile 2020 215mm
- 2 x Alu Profile 2020 670mm
- 100 x ISO 7380 M5
- 100 x Nut 5 M5
- 12 x Exhaust Alu Plates



Notes:

Glue all the outside corners with any other Alu Bracket (eg scrap pieces of 40x40x2mm)

Exhaust Installation

Building manual v0.1 Daniele Ingrassia 08.2018







Notes:

Materials:

- 50 x ISO 7380 M5
- 50 x Nut 5 M5

- Attach the Exhaust from the internal side of the machine
- Place beforehand the Nut 5 M5 in position

Building manual v0.1

11

X Axis Assembly

Materials:

- 1 x HGR 15mm Linear Guide 1700mm
- 1 X HGH 15mm Carriage
- 29 x Nut 4 M8
- 29 x DIN 912 M4 20mm
- 1 x Alu Profile 4040 x 1800mm
- 1 x T5 16mm, 4000mm long
- 1 x DIN 912 M8 40mm
- 4 x DIN 912 M8 35mm
- 8 x DIN 912 M3 60mm
- 2 x 608 Ball Bearing
- 5 x WS9240 M8 30mm Washers
- 2 x DIN 125 M8 Washers
- 6 x X-Axis POM
- 2 x POM Laser Head
- 1 x C02 Laser Head
- 1 x Yag Laser Head
- 1 x POM Mirror Holder
- 1 x 2nd Mirror C02
- 1 x 2nd Mirror YAG
- 1 x X-axis Nema 24
- 1 X 16mm T5 16 pulley
- 1 x Alu X-axis Stepper Holder
- 4 x DIN 912 M4 30mm
- 4 x DIM 985 M4
- 2 x Endstops
- 2 x POM Endstops Holders





- Keep the linear guide in the center of the 4040 Alu profile
- Cut the belt at a length to have enough tension
- Put the green caps on the guide after the assembly

Y Axis Installation

000

Materials:

- 1 x 12mm Linear Rod 860mm
- 1 x 12mm Linear Rod 840mm
- 1 x Nema 24 Stepper
- 1 x POM Y-Axis Stepper Holder
- 8 x POM Y-Rod Holder
- 4 x POM Y-Bearing Holder
- 4 x 628 Ball Bearing
- 2 x Belt T5 20mm, 2500mm
- 2 x HGR 15mm linear guide 1200mm
- 2 x HGW 15mm Carriage
- 2 x Pulley T5 20mm 16
- 12 x DIN 912 M4 30mm
- 12 x DIN 985 M4
- 20 x DIN 912 M8 20mm
- 20 x Nut 8 M8
- 4 x 608 Ball Bearing
- 2 x DIN 912 M8 40mm
- 4 x DIN 125 Washers
- 10 x WS2940 M8 Washer 30mm
- 2 x Coupler 8mm to 12mm
- 4 x Endstop
- 4 x POM Endstop Holder
- 48 x DIN 912 M4 20mm
- 48 x Nut 8 M5







Notes:

- Keep the linear guide in the center of the 4040 Alu profile
- Cut the belt at a length to have enough tension
- Put the green caps on the guide after the assembly
- Hammer the 12mm rod inside the bearing carefully

Building manual v0.1 Daniele Ingrassia 08.2018



X Axis Installation



Materials:

• 8 x DIN 912 M4 25mm





Building manual v0.1

Daniele Ingrassia

- Move the Y-bearing holder to increase/decrease the tension
- Use a DIN 875 to make sure the X-Axis is perpendicular to the Y-Axis, close the belts afterwards

Laser Frame Installation

Building manual v0.1 Daniele Ingrassia





Materials:

- 2 x 4080 Alu Profile 340mm
- 1 x 4080 Alu Profile 1500mm
- 1 x 4080 Alu Profile 1540mm
- 2 x 80x80 Bracket
- 12 x 40x40 Bracket
- 16 x DIN 912 M8 20mm
- 24 x DIN 916 M8 16mm
- 40 x Nut 8 M8



Notes:

• Make sure the surface of the 4080 1500/1540mm is parallel to the surface of the frame

Laser Installation





Materials:

- 1 x C02 Laser Tube
- 1 x Yag Cavity
- 1 x First Mirror C02
- 1 x First Mirror YAG
- 4 x DIN 912 M5
- 4 x Nut 8 M5
- 16 x Nut 8 M5
- 16 x DIN 912 M8 25mm
- 2 x POM C02 Holder
- 2 x C02 Tube Holder
- 4 x POM Yag Holder





- Be careful with the glass tube, it can break very easily
- Position the laser tube brackets as written on the tube
- Position the YAG laser as close as possible to the 1st mirror



- 2 of this frame are needed for both sides
- Don't tight too much the 3d printed parts
- The height of the short 4080 profiles is 80mm from the top frame Daniele Ingrassia 08.2018

Body Frame Front

. P

Materials:

• 1 x 4040 Alu Profile 1900mm

- 2 x 4040 Alu Profil 480mm
- 2 x 4040 Alu Profil 350mm
- 2 x 4040 Alu Profil 177mm
- 2 x 4040 Alu Profil 150mm
- 4 x Nut 8 M8
- 16 x DIN 912 M8 20mm
- 6 x POM Front Frame Holder
- 2 x 3D Printed Round Shoulders
- 2 x 3D Printed Fillet
- 2 x 3D Printed Top Corner
- 2 x 3D Printed Front Legs
- 16 x DIN 912 M8 20mm
- 16 x Nut 8 M8







Notes:

• Don't tight too much the 3d printed parts Daniele Ingrassia

08.2018

Body Frame Back

Materials:

- 1 x Alu Profile 4080 1700mm
- 1 x Alu Profile 4040 2000mm
- 1 x Alu Profile 4040 1500mm
- 2 x Alu Profile 4040 700mm
- 2 x Alu Profile 4040 177mm
- 2 x Alu Profile 4040 350mm
- 4 x POM Back Frame Holder
- 2 x 3D Printed Fillet
- 2 x 3D Printed Round Shoulders
- 2 x 3D Printed Square Shoulders
- 9 x Bracket 40x40
- 29 x DIN 912 M8 16mm
- 29 x Nut 8 M8



Building manual v0.1

Notes:

Eventually short the Alu Profiles in case they are too long

Materials:

- 1 x Alu Profile 4080 1589mm
- 1 x Alu Profile 4080 99mm
- 2 x Alu Profile 4040 1900mm
- 2 x Alu Profile 4040 250mm
- 2 x POM Holder Top Frame
- 4 x Bracket 40x80
- 4 x Bracket 40x40
- 8 x DIN 912 M8 16mm
- 16 x DIN 912 M8 20mm
- 24 x Nut 8 M8

Notes:

• Eventually short the Alu Profiles in case they are too long

Building manual v0.1

Housing Back

- 1 x Alu Plate Back Top
- 1 x Alu Plate Back Bottom
- 1 x Alu Plate Bottom
- 3 x Alu Plate Bottom Air Intake
- 2 x 3D Printed Back Bracket
- 69 x ISO 7380 M8 12mm
- 69 x Nut 8 M8
- 12 x DIN 912 M8 16mm
- 12 x DIN 125 Washer M8
- 12 x DIN 985 M8
- 50 x ISO 7380 M5
- 50 x Nut 5 M5

Notes:

Place beforehand the Nut 8 M8 to facilitate the screwing

Housing Sides

Materials:

- 2 x Alu Plate Side Bottom
- 2 x Alu Plate side Top
- 144 x ISO 7380 M8 12mm
- 144 x Nut 8 M8

- Place beforehand the Nut 8 M8 to facilitate the screwing
- 3D Print some special spacers for the bottom screws

Building manual v0.1

Housing Front

Materials:

- 1 x Alu Plate Front
- 1 x Alu Plate Front Center
- 1 x Alu Air Intake Front
- 67 x ISO 7380 M8 12mm
- 67 x Nut 8 M8

Notes:

Place beforehand the Nut 8 M8 to facilitate the screwing

Housing Inside

Materials:

- 1 x Alu Plate Front Top
- 1 x Alu Inside Back
- 1 x Alu Inside Side
- 48 x ISO 7380 M8 12mm
- 48 x Nut 8 M8

Notes:

Place beforehand the Nut 8 M8 to facilitate the screwing Daniele Ingrassia 08.2018

Building manual v0.1

Window Assembly

- 1 x LaserVision 1200x900mm 6mm P1P12
- 1 x Alu Plate Window Front
- 1 x Alu Plate Window Back
- 2 x Alu Plate Window Connector
- 1 x Linear Rod 15mm 2000mm
- 2 x POM Window Holder
- 4 x Ball Bearing 6802
 82 x ISO 7380 M8 20mm
- 82 x DIN 985 M8
- 82 x DIN 125 M8
- 4 x Alu Bracket 30x40 x 1500mm
- 4 x Alu Bracket 40x40 x 2000mm
- 6 x Alu Plate Window cover

Notes:

- Drill manually the window bracket checking the holes with the CNC milled plates
- Sandwich and screw the P1P12 with double side tape in between

Building manual v0.1 Daniele Ingrassia 08.2018

Window Installation

Building manual v0.1 Daniele Ingrassia 08.2018

Materials:

- 4 x Nut 8 M8
- 4 x DIN 933 M8 20mm
- 2 x POM Window Holder
- 2 x Hydraulic Spring 250N 250-500mm
- 4 x DIN 912 M8 30mm
- 4 x DIN 985 M8
- 8 x DIN 125 Washer M8

Notes:

• Attach the hydraulic springs as last step

Tablet Installation

Materials:

- 1 x Alu Tablet Enclosure With Tablet
- 1 x Bracket 40x80
- 1 x ISO 7380 20mm
- 1 x DIN 912 80mm
- 2 x DIN 985 M8

Notes:

Drill manually an hole to the shoulder to fix the tablet enclosure using a 40x80 bracket Daniele Ingrassia 08.2018